

Key Light Diagnostics



AutoTraq & Standard Keys Only

Slow bright flashing initially	Fast flashing red or green (normal action) – key looking for lock	Slow bright flashing (diagnostic signals)	Diagnosis	Recommended action
*** (2 flashes)	* * * * *		Low battery	Change battery
	* * * * * * * * * *	None	If the door doesn't open, the lock is not powered	Use battery back-up*. Check wiring to lock or replace vendor control
	* * * * *	*** (3 flashes)	Key disabled	Refresh key at cradle
	* * * * *	***** (5 flashes)	Wrong key	Use lock reader to determine correct key then access with the correct key

Check keys everyday prior to starting work

*(see page 6)

Unlocking BevIQ® and SnackIQ®



Unlocking

- Hold Key 1 to 3 inches from receiver
- Press center button on key
- Listen for motor and handle should release.
- **Solid Bright Light** = correct key / normal state (see key light diagnostics for other sequences)

Locking BevIQ® and SnackIQ®

Locking

- If operator is a threaded bolt, make sure handle is in a free-moving state before latching into place by overturning the handle clockwise about 1/8 turn past latched position and turn handle counterclockwise to latched position
- Push the handle until latched into place

